

Jacquard Printable Fabric

Inkjet Printable Fabric

Unlike other inkjet fabrics, **Jacquard Inkjet Cotton, Silk and Organza** retain the natural hand of the fabric. This fabric will run through your desktop inkjet printer just like paper. The results are permanent; light fast, hand washable, and soft & supple.

JPAC9701 – Inkjet Cotton - 8.5" x 11" 10pce pack

JPAC9702 – Inkjet Silk - 8.5" x 11" 10pce pack

JPAC9703 – ExtravOrganza – 8.5" x 11" 5pce pack

PLEASE NOTE - IMPORTANT: Sheets are in American Letter format. When printing your images you should remember to set your printer to this format.



Jacquard Inkjet Fabric Instructions

These sheets are paper backed so that they will easily go through your inkjet printer. They are not transfer paper and do not contain any sort of adhesive. To adhere the fabric to your project you can sew or use a fusible bonding material such as Stitch Witchery, Fus-O-Bond, or Wonder Under Craft depending on the surface you are adhering to.

Steps:

1. Before you print onto your fabric sheet, run a test on paper to check for orientation and alignment of your image. You may also want to change your printer settings to get the most ink onto the fabric as possible up to the point of bleeding. This way you will get a more saturated image. Every printer is different so it is a good idea to test different settings.
2. Load one sheet of Jacquard Inkjet Silk, Cotton or Organza at a time and print your image.
3. Peel the fabric from the paper backing.
4. Let dry for 24 hours if item is to be washed. Hand wash with cool water and light soap.
5. Your printed fabric is now ready to use!